


GARDEN

BRAND

GB 1210C  
Rocker Seat Cushion



## Easy Assembly



1. Slide the two back straps UP through the slots on back of the seat. Attach the straps to the cushion bottom as shown.

2. Flip the seat upside down. Feed the remaining straps on each side through the TOP of the seat and attach as shown.

## CAUTION:

*This product is design  
for sitting only.  
DO NOT STAND on!*



## WARNING:

*Not intended for  
use by children.*



## LIMITED WARRANTY

Vertex International warrants this product against defects in materials or workmanship during normal use for 2 years from date of purchase.

Call 1-877-283-7839 and Vertex will repair or replace the product at Vertex's sole discretion. **Vertex shall not be liable for incidental or consequential damages resulting from the use of this product. Vertex does not assume responsibility for defects, damage, or injury caused by mis-use, abuse, or alterations. Vertex makes no warranty with respect to the suitability of this product for specific applications. We recommend the end-user determine such suitability for any specific use.**



Vertex International  
Minnesota, U.S.A.  
1-877-283-7839  
[www.2vertex.com](http://www.2vertex.com)